

TRANSFER 1:  
Place the print centered  
between the horizontal  
and vertical seams

TRANSFER 2:  
Place the print centered  
horizontally between the seams  
and vertically between  
the indicated points

TRANSFER 3:  
Place the print centered  
horizontally between the seams  
and vertically between  
the indicated points





COLOR:  
GREEN  
C 100%, M 0%, Y 100%, K 70%



COLOR:  
TPX  
11-0604



TRANSFER S2011B  
FOR MODEL 717



COLOR:  
TPX  
11-0604





COLOR:  
TPX  
11-0604

